ShoreTel 265 IP Phone Quick Reference

PHONE OPERATION

Place Calls

Use the Speakerphone or a Headset

Use the Directory

Make a Conference Call

Use the Intercom

Redial and Check Missed Calls

Dial Paging Extension

Answer Calls

Send a Call to Voice Mail

Divert a Call

Select a Ring Tone

Adjust Handset, Headset,

or Speakerphone Volume

Answer Call Waiting

Interact with Calls

Mute a Call

Place a Call On or Off Hold

Transfer a Call

Join Calls


Park Calls

Unpark Calls

Change Call Handling Mode


Log In and Out of Workgroups

Adjust the Display Contrast





select appropriate call key



VOICE MAIL

Log Into the Main Menu

+ password + # # # + ext. + password + #

Log In from Another Extension

Note: For more information about voice mail features, please consult the Voice Mail Quick Reference.

OFFICE ANYWHERE CODES

Transfer a call

* * + destination + # #

Conference a call

* * + destination + * *

Hang up ###

Access other star codes * * + (star code from below)

QUICK REFERENCE OF COMMON STAR CODES

 Park a call
 * 1 1 + ext.

 UnPark a call
 * 1 2 + ext.

 Pick Up a Remote Extension
 * 1 3 + ext.

Pick Up the Night Bell

Use the Intercom

* 1 5 + ext.

Barge In

* 1 6 + ext.

Silent Monitor

* 1 7 + ext.

Toggle the Hunt Group Status

* 1 8 + HG ext.

Whisper Page

* 1 9 + ext.

Voice Mail + password + #

Change Extension Assignment

Unassign Extension Assignment

Voice Mail + password + # + password

Assign Extension to External Number

Voice Mail
+ password + # + 7 3 3


TROUBLESHOOTING

View Phone Information $4 \bigcirc + I-N-F-O + 4 \bigcirc + R-E-S-E-T + 4 \bigcirc + R$

Note: For additional information beyond that which is contained in this Quick Reference card, please consult the IP 265 User Guide.



ShoreTel 265 IP Phone Quick Reference



Note: You can connect a supported headset into the 265 IP Phone by plugging the headset into the headset jack at the left corner of the phone chassis. Contact your system administrator for details.


GUIDE TO LEDS

Your ShoreTel 265 IP phone provides color cues to help you determine the operational status. Note that these patterns apply to ShoreTel 6.1 (build 11.15.2603.0) and higher.


- Steady Green in use by you
- Blinking Green (Slow blink: 1s on/1s off) incoming call
- Blinking Orange (Fast blink: .25s on/.25s off) on hold or call parked
- Steady Orange extension's call handling mode set to Do Not Disturb
- Steady Red in use by other party (applies to BCA and Extension Monitor)

GUIDE TO STATUS ICONS


ShoreTel IP 265 Idle Interface



ShoreTel IP 265 Outbound Call



Main Display



Missed Calls

Logged Into Workgroup

Logged Into Workgroup, In Wrap-Up

X Logged Out of Workgroup

Custom Keys - Call

On Hook

🚣 Off Hool

Inactive / Do Not Disturb

Incoming Call (Animated)

" On a Call

🗗 On a Conference Call

Call On Hold / Parked

Remote Hold

Custom Keys - Monitored Extension

Idle

Inactive / Do Not Disturb

Unheard Voice Messages

● Do Not Disturb / Unheard Messages

Incoming Call (Animated)

On a Call

Incoming Call and On a Call

On a Conference Call

On a Call and Call Parked

Custom Keys - Speed Dial

Speed Dial Extension

