

# LASSITER TROJAN BAND HEMMING GUIDELINES

## ABSOLUTELY NO CUTTING OF FABRIC!

- Straps at shoulders of the bibber should be adjusted for comfort prior to hemming.
- Bibbers should be worn so that the pant leg creases with the classic break (image below).



- The length should come approximately to the second eyelet of the marching shoe.
- Use the snaps inside the pant leg; however, it is more important to hem to the correct length rather than rely on the snaps.
- Hem should be sewn using black thread.
- **DO NOT** use safety pins, fusible webbing, hemming tape, or duct tape for hems.
- **DO NOT ALTER** any other part of the bibber. **DO NOT** take in or let out the side seams of the bibber.